Welcome to RISO SC7000

Thank you very much for purchasing the RISO SC7000.
This manual provides various information ranging from advanced operational descriptions to safety precautions and troubleshooting tips, to allow you to make the most use of the SC7000.
We recommend, therefore, that you keep this manual within your reach and refer to it before and during operation if required.

This document is intended for use by RISO, Incorperated, its authorized dealers and purchasers of the equipment described herein. While every effort has been made to insure the accuracy of information contained in this document, RISO, Inc., its authorized dealers and their employees shall not be held responsible for any inaccuracies it may contain.

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can rediate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which cause the user will be required to correct the interference at his own expense.

This document contains proprietary information and it may not be reproduced in whole or in part without prior written authorization by RISO, Inc., Marketing Department, 300 Rosewood Drive, Danvers, MA 01923.

Additional copies of this manual are available through RISO Customer Service at (800) 995-RISO (voice) or 508-777-6280 (Fax) .

Copyright © 1996 RISO Kagaku Corporation, JAPAN

Notes

(1) Reproduction or copying of this manual or any parts thereof without permis sion is strictly prohibited.
(2) The contents of this manual are subject to change without notice due to product improvements in the future.
(3) Although every effort has been made to ensure that the contents of this manual are error-free, please contact us if you notice any errors or other points which should be brought to the company's attention.
(4) Item (3) notwithstanding, we cannot be held liable for any effects which have resulted from following the instructions contained in this manual or from the operation of the machine.

* "Windows® Version 3.1" and "Windows® 95" are registered marks of Microsoft Corporation. It is referred to as "Windows 3.1" and "Windows 95" in this manual.
* "MS-DOS®" is a registered mark of Microsoft Corporation.
* "Macintosh®" is a trademark of Apple Corporation. It is referred to as "Macintosh" in this manual.
* "Adobe®", "PostScript®", and "PostScript Logo" are trademarks of Adobe Systems Incorporated.
* The other brand and product names may be registered marks or trademarks of their respective holders.

Contents 1

1. Contents 3
   1.1 Table of Contents 3
   1.2 List of Figures 7
2. Introduction 11
   2.1 Scope of This Manual 11
   2.2 SC7000 Specifications 12
   2.3 Before Using 13
      2.3.1 Precautions for Installation 13
      2.3.2 Precautions for Usage 14
      2.3.3 Handling the CD-ROM 14
3. Unpacking 15
   3.1 Checking Your SC7000 Package 15
   3.2 Front and Rear Panel Controls 16
4. Hardware Installation 17
   4.1 Serial Port 18
   4.2 Parallel Port 19
   4.3 Network 20
      4.3.1 Ethernet Connectors 20
         4.3.1.1 10Base2 21
         4.3.1.2 10BaseT 22
         4.3.1.3 AUI 22
      4.3.2 Network Protocols 23
         4.3.2.1 EtherTalk 23
         4.3.2.2 TCP/IP 24
            4.3.2.2.1 TCP/IP Workstation Setup 25
   4.4 SCSI Port 26
   4.5 RISOGRAPH 27
   4.6 Mains Supply (Alimentation secteur) 27

1.1 Table of Contents

5. Software Installation 29
5.1 Apple Macintosh and Compatible Computers 30
5.1.1 Printer Driver, Scanner Driver, and SC7000 Utility 30
5.1.2 Screen Fonts 32
5.1.3 PDFs (Printer Description Files) 32
5.2 Microsoft Windows 33
5.2.1 PostScript Printer Driver 33
5.2.2 PCL Printer Driver 37
5.2.3 SC7000 Utility, Scanner Driver 39
5.2.4 Screen Fonts 40
5.3 MS-DOS 42
5.3.1 SC7000 Utility and Scan Utility 42
6. System Setup 43
6.1 Apple Macintosh and Compatible Computers 43
6.1.1 Printer Driver 43
6.1.1.1 Printer Selection 43
6.1.1.2 Printer Driver Setup 44
6.1.1.3 Print Options 46
6.1.2 SC7000 Utility 49
6.1.2.1 The File Menu 49
6.1.2.2 The Edit Menu 51
6.1.2.3 The Utilities Menu 51
6.1.2.3.1 Basic Functions 51
6.1.2.3.2 Specific Functions 53
6.2 Microsoft Windows 59
6.2.1 PostScript Printer Driver for Windows 3.1x 59
6.2.1.1 The Paper Tab 60
6.2.1.2 The Features Tab 62
6.2.1.3 The Fonts Tab 63
6.2.1.4 Font Downloader 64
6.2.1.4.1 General Options 64
6.2.1.4.2 Other Options 66
6.2.1.5 The PostScript Tab 68
6.2.1.6 The Job Control Tab 70
6.2.1.7 The Watermark Tab 71
6.2.2 PostScript Printer Driver for Windows 95 73
6.2.2.1 The General Tab 74
6.2.2.2 The Details Tab 75
6.2.2.3 The Paper Tab 76
6.2.2.4 The Graphics Tab 79

6.2.2.5 The Fonts Tab 80
6.2.2.5.1 The Font Substitution Table 81
6.2.2.5.2 The Send TrueType Fonts as Option 82
6.2.2.6 The Device Options Tab 83
6.2.2.7 The PostScript Tab 84
6.2.2.8 The Watemarks Tab 87
6.2.3 PCL Printer Driver for Windows 3.1x 89
6.2.3.1 The Setup Dialog Box 89
6.2.3.2 The Options Dialog Box 90
6.2.3.3 The HP Font Installer Dialog Box 91
6.2.4 PCL Printer Driver for Windows 95 94
6.2.4.1 The General Tab 95
6.2.4.2 The Details Tab 96
6.2.4.3 The Paper Tab 97
6.2.4.4 The Graphics Tab 99
6.2.4.5 The Fonts Tab 100
6.2.4.6 Font Downloader 101
6.2.4.6.1 Installing Fonts 102
6.2.4.6.2 Downloading Fonts 102
6.2.4.6.3 Moving Fonts 103
6.2.4.7 The Device Options Tab 103
6.2.5 SC7000 Utility 105
6.2.5.1 The File Menu 105
6.2.5.2 The Print Menu 106
6.2.5.3 The Setup Menu 107
6.2.5.3.1 General 107
6.2.5.3.2 Printing 108
6.2.5.3.3 PostScript 110
6.2.5.3.4 Communication 111
6.2.5.3.5 LaserJet Emulation (PCL) 112
6.2.5.4 The Maintenance Menu 113
6.2.5.5 The Help Menu 113
6.3 MS-DOS 114
6.3.1 SC7000 Utility 114

7. Appendix 119
7.1 SC7000 Test Procedure 119
7.1.1 Check The Basics 119
7.1.2 Reset The System 119
7.1.3 Perform The Self Test 120
7.1.4 Locate The Communication Problem 120
7.1.5 Restore The Factory Defaults 121
7.1.6 Contact Your RISO Dealer 121
7.2 Test Pages 121
7.2.1 Self Test Page 121
7.2.2 Settings Page 122
7.2.3 Font List Page 122
7.2.4 Sample Page 122
7.2.5 PostScript Font Sample Page 122
7.2.6 PCL Font Sample Page 123
7.3 Factory Default Settings 123
7.3.1 General Defaults 123
7.3.2 Printing Defaults 123
7.3.3 PostScript Defaults 124
7.3.4 Communication Defaults 124
7.3.4.1 EtherTalk 124
7.3.4.2 TCP/IP 124
7.3.4.3 Serial Port 124
7.3.4.4 Printing Port 124
7.3.4.5 SCSI ID 124
7.3.5 LaserJet Emulation (PCL) 124
7.4 Connector Pin Assignments 125
7.4.1 Serial Port 125
7.4.2 Parallel Port 126
7.4.3 Network 127
7.4.3.1 10Base2 127
7.4.3.2 10BaseT 127
7.4.3.3 AUI 128
7.4.4 SCSI Port 129
7.5 Specifications 131
Index 133

1.2 List of Figures

Figure 3.1: Components in the SC7000 package 15
Figure 3.2: Front and Rear Panel Controls 16
Figure 4.1: Cable Connections 17
Figure 5.1: SC7000 Installer (Macintosh compatible) 30
Figure 5.2: SC7000 Customizer (Macintosh compatible) 32
Figure 5.3: Install PostScript Printer From PPD Dialog Box (Windows) 34
Figure 5.4: Properties Dialog Box / Details Tab (Windows 95) 35
Figure 5.5: Connect Dialog Box (Windows 3.1x) 36
Figure 5.6: Add Printer Wizard Dialog Box (Windows 95) 37
Figure 5.7: Printers Dialog Box (Windows 3.1x) 38
Figure 5.8: Write's & WordPad's Fonts Dialog Box (Windows) 40
Figure 6.1: Chooser (Macintosh compatible) 43
Figure 6.2: PPD File Selection (Macintosh compatible) 45
Figure 6.3: Installable Options Dialog Box (Macintosh compatible) 45
Figure 6.4: Page Setup Dialog Box (Macintosh compatible) 46
Figure 6.5: Custom Paper Size (Macintosh compatible) 47
Figure 6.6: Page Setup Options (Macintosh compatible) 48
Figure 6.7: Download Fonts (Macintosh compatible) 49
Figure 6.8: Display Available Fonts (Macintosh compatible) 50
Figure 6.9: Name Printer (Macintosh compatible) 51
Figure 6.10: Get Page Count (Macintosh compatible) 52
Figure 6.11: Change Zone (Macintosh compatible) 53
Figure 6.12: SC7000 Print Page (Macintosh compatible) 53
Figure 6.13: SC7000 Setup General (Macintosh compatible) 54
Figure 6.14: SC7000 Setup Printing (Macintosh compatible) 55
Figure 6.15: SC7000 Setup PostScript (Macintosh compatible) 56
Figure 6.16: SC7000 Setup Communication (Macintosh compatible) 57
Figure 6.17: PostScript Printer Driver Setup / Paper Tab (Windows 3.1x) ... 60
Figure 6.18: Custom Paper Dialog Box (Windows 3.1x) 61
Figure 6.19: PostScript Printer Driver Setup / Features Tab (Windows 3.1x) 62
Figure 6.20: PostScript Printer Driver Setup / Fonts Tab (Windows 3.1x) ... 63
Figure 6.21: Adobe PostScript Font Downloader Dialog Box (Windows 3.1x) 65
Figure 6.22: PostScript Font Downloader / Other Options (Windows 3.1x) . 66
Figure 6.23: PostScript Printer Driver Setup / PostScript Tab (Windows 3.1x) 68
Figure 6.24: PostScript Printer Driver Setup / Job Control Tab (Windows 3.1x) 70
Figure 6.25: PostScript Printer Driver Setup / Watermark Tab (Windows 3.1x) 71

Figure 6.26: Edit Watermark Dialog Box (Windows 3.1x) 72
Figure 6.27: PostScript Printer Driver Setup / General Tab (Windows 95) .. 74
Figure 6.28: PostScript Printer Driver Setup / Details Tab (Windows 95) 75
Figure 6.29: PostScript Printer Driver Setup / Paper Tab (Windows 95) 76
Figure 6.30: PostScript Printer Driver Setup / Custom Paper Dialog Box (Windows 95) 77
Figure 6.31: PostScript Printer Driver Setup / Unprintable Area Dialog Box (Windows 95) 78
Figure 6.32: PostScript Printer Driver Setup / Graphics Tab (Windows 95) . 79
Figure 6.33: PostScript Printer Driver Setup / Fonts Tab (Windows 95) 80
Figure 6.34: PostScript Printer Driver Setup / Edit The Table Dialog Box (Windows 95) 81
Figure 6.35: PostScript Printer Driver Setup / Send Font as Dialog Box (Windows 95) 82
Figure 6.36: PostScript Printer Driver Setup / Device Options Tab (Windows 95) 83
Figure 6.37: PostScript Printer Driver Setup / PostScript Tab (Windows 95) 84
Figure 6.38: PostScript Printer Driver Setup / Advanced PostScript Options dialog box (Windows 95) 86
Figure 6.39: PostScript Printer Driver Setup / Watermarks Tab (Windows 95) 87
Figure 6.40: Edit Watermark Dialog Box (Windows 95) 88
Figure 6.41: PCL Printer Driver / Setup Dialog Box (Windows 3.1x) 89
Figure 6.42: PCL Printer Driver / Options Dialog Box (Windows 3.1x) 90
Figure 6.43: PCL Printer Driver / HP Font Installer (Windows 3.1x) 91
Figure 6.44: PCL Printer Driver / General Tab (Windows 95) 95
Figure 6.45: PCL Printer Driver / Details Tab (Windows 95) 96
Figure 6.46: PCL Printer Driver / Paper Tab (Windows 95) 97
Figure 6.47: PCL Printer Driver / Graphics Tab (Windows 95) 99
Figure 6.48: PCL Printer Driver / Fonts Tab (Windows 95) 100
Figure 6.49: PCL Printer Driver / HP Font Installer (Windows 95) 101
Figure 6.50: PCL Printer Driver / Device Options Tab (Windows 95) 103
Figure 6.51: General Dialog Box (Windows) 107
Figure 6.52: Printing Dialog Box (Windows) 108
Figure 6.53: PostScript Dialog Box (Windows) 110
Figure 6.54: Communication Dialog Box (Windows) 111
Figure 6.55: LaserJet Emulation (PCL) Dialog Box (Windows) 112
Figure 6.56: File Menu (MS-DOS) 115
Figure 6.57: Print Menu (MS-DOS) 115
Figure 6.58: Setup Menu (MS-DOS) 116

Figure 6.59: Maintenance Menu (MS-DOS) 116
Figure 6.60: Info Menu (MS-DOS) 117
Figure 6.61: Download Font (MS-DOS) 117
Figure 6.62: Printing Port (MS-DOS) 118
Figure 6.63: Select SCSI ID (MS-DOS) 118
Figure 7.1: Serial Port D-Sub 9-pin Plug 125
Figure 7.2: Parallel Port D-Sub 25-pin Receptacle 126
Figure 7.3: Ethernet 10Base2 BNC Receptacle 127
Figure 7.4: Ethernet 10BaseT RJ-45 Receptacle 127
Figure 7.5: Ethernet AUI D-Sub 15-pin Receptacle 128
Figure 7.6: SCSI 50-pin Receptacle 129